


## RS232 Connection Between MMI6070 and TRi Super PLC (exluding Nano-10)



## RS485 Connection Between MMI6070 and TRi Super PLCs (Required for Nano-10)

